

# Scoreboard Controller – NEVCO 871

## START A NEW GAME

1. Turn clock on (button on right side of unit). If clock is already on, turn unit off then on.
2. PROMPT: START WHERE TURNED OFF LAST? → Press **NO** key.
3. PROMPT: GO TO A BOOKMARK? → Press **NO** key.
4. PROMPT: ENTER YOUR MODEL CODE → Enter **871**, using number keys. Do Not Press Yes. The word “Hockey” will display briefly.
5. PROMPT: DO YOU WANT TO USE PENALTY TIME OUT? → Press **NO** key. The time and direction it will count will display: [0.00.0 DN]

## SET A NEW PERIOD

1. Press **SET** key 2.  
Press **TIME** key.
3. PROMPT: SET MM:SS.s → Enter period length (i.e. 10:00.0 or 12:00.0 - you must enter ALL digits, including all zeros). Press **YES** key.
4. PROMPT: PERIOD 0 → Enter period number, using number keys. Clock is automatically set to count down.
5. Use hand-held switch to start and stop the clock. Top button is timer run toggle and bottom button is manual horn.

Note: The Time On and Time Off keys are disabled if hand-held switch is plugged into unit.

Important: Turn timer run off at end of period or else the clock will automatically start running after you set the next period!

## ENTER OR EDIT THE SCORE

1. Press **SET** key
2. Press **HOME SCORE** key or **GUEST SCORE** key
3. Enter the correct score using number keys (i.e. 1, 2, etc.)
4. Press **YES** key

## ENTER A PENALTY

1. Press **SET** key
2. Press **HOME PENALTY** key or **GUEST PENALTY** key
3. PROMPT: PEN MM:SS → Enter the penalty length in minutes. Must enter as 2-digit minutes with zero seconds (i.e. 02:00)
4. Press **YES** key
5. PROMPT: H.PLAYER# or G.PLAYER# → Enter 2-digit player number, using number keys (i.e. 09 or [Blank] key & 9 for Player #9)
6. Press **YES** key
7. The penalty clock will start once the timer is run

## CANCEL A PENALTY

1. Press **HOME PENALTY** key or **GUEST PENALTY** key to recall first penalty to control.
2. Each time you press Home Penalty key or Guest Penalty key, the next penalty on the list will display.
3. Press **PENALTY CLEAR** key.
4. PROMPT: CLEAR Y-N → Press **YES** key.